


# Élan DX20



## Quick start guide

Kurzreferenz

Aide-mémoire

Guida rapida

Guía rápida


Vlugge gids

Snabbguide



Lynvejledning

12J60

## 1 Aerial - Antenne - Antenna - Antena - Antenn







## 2 Power - Stromversorgung - Alimentation - Alimentazione - Alimentación - Stroom - Ström





## 3 Volume - Lautstärke - Volumen - Volym - Lydstyrke






## 4 Station - Sender - Stazione - Emisora




## 5 Presets - Belegungen - Présélections - Memorie - Presintonias - Voorafinstellingen - Förinställda stationer




## Recall - Abrufen - Rappel - Richiama - Recorder - Heroproepen - Hämta - Genkald



## 6 Info - Informationen - Información - Information




## 7 Autotune - Autotunen - Réglage automatique - Sintonizzazione automatica - Sintonización automática - Ställ in automatiskt



## 8 On - Ein - Activé - Activado - Aan - På - Tænd



## 9 Sleep - Einschlafen - Veille - Desconexión - Slaap



**Élan DX20**

**PURE Digital**  
Imagination Technologies Ltd.,  
Imagination House,  
Home Park Estate,  
Kings Langley, Herts., WD4 8LZ, UK

**For support**  
Telephone: +44 (0) 1923 277477  
E-mail: support@pure.com  
Web: www.pure.com

**PURE**